

HI FLOW CUPLA Flange mount type

CUPLA Series for Temperature Control Equipment Piping


Semi-standard product

Built-in valve

No welding, flanges, or hose barbs required!
Can be directly installed in a variety of manufacturing equipment.


Temperature control equipment (Chiller)

Installation example of main cooling water piping



Hex socket head cap screws (M4) for fastening to the flange are not included.

Size comparison with SP CUPLA Type A
(Comparing sockets with the same connection size)

SP CUPLA Type A
Model: 4S-A

HI FLOW CUPLA
Model: HFL-4S

- Diamond-shaped flange allows for installation at close intervals.
- Both the plug and socket have built-in automatic shut-off valves.
- High flow characteristics for enhanced cooling effect.
- Enables quick connection and disconnection of cooling pipes.
- Compact, space-saving design with up to 22% shorter connection length compared to previous models.
- Allows for easy and quick installation and maintenance.

Specifications

Body material	Stainless steel (SUS304)			
Size (Thread)	1/4", 3/8", 1/2"			
Pressure unit	MPa	kgf/cm ²	bar	PSI
Working pressure *1	1.0	10	10	145
Seal material	Seal material		Mark	Working temperature range
Working temperature range *2	Ethylene-propylene rubber		EPDM	-40°C to +150°C


*1: The normal allowable fluid pressure under continuous use.

Exceeding the working pressure may cause damage and leakage.


*2: The operable temperature range depends on the operating conditions.

⚠ Safety Guide

- Do not apply pressure to CUPLA socket or plug while they are disconnected.
- Do not use CUPLA continuously exceeding the rated working pressure.
- Only use CUPLA that are within their rated temperature range.
- Do not exceed the recommended maximum torque when installing CUPLA.
- The flange type does not include hex socket head cap screws (M4) or other components for fixing to the flange.
Please select hex socket head cap screws of appropriate length for installation.
- Care must be taken when installing CUPLA not to overtighten or cross thread.
- Do not connect/disconnect with fluid still under dynamic pressure or static residual pressure.
- Do not strike the tip of an automatic shut-off valve with a hammer or a similar tool.
However, if you need to relieve residual pressure, please consult us.

Plug HFL- **P-FL type (Flange mount type for low pressure)****Socket** HFL- **S-FL type (Flange mount type for low pressure)**

Model	Application (Thread)	Mass (g)	Dimensions (mm)										Model	Application (Thread)	Mass (g)	Dimensions (mm)									
		Stainless steel	L1	L2	L3	L4	C	øD1	øD2	H (WAF)	T	Stainless steel			L1	L2	L3	L4	øD1	øD2	H (WAF)	T			
HFL-2P-FL	See drawings below	45	30	(21.5)	2	50	16.5	(32)	21	Hex.19	Rc 1/4	HFL-2S-FL	See drawings below	108	(46.5)	(24.7)	2	50	(32)	26	19	Rc 1/4			
HFL-3P-FL		63	31	(23.5)		55	18	(37)	25	Hex.23	Rc 3/8	HFL-3S-FL		166	(49)	(26.8)		55	(37)	32	24	Rc 3/8			
HFL-4P-FL		95	37.5	(29)		60	22.5	(41)	32	Hex.29	Rc 1/2	HFL-4S-FL		232	(60)	(30.7)		60	(41)	35	29	Rc 1/2			

Dimensions for Mounting

Model	Dimensions (mm)		Model	Dimensions (mm)	
	øD1	D2		øD1	D2
HFL-2P-FL	21.5 ^{+0.2} ₀	PCD40±0.2	HFL-2S-FL	25 ^{+0.2} ₀	PCD40±0.2
HFL-3P-FL	25.5 ^{+0.2} ₀	PCD45±0.2	HFL-3S-FL	30 ^{+0.2} ₀	PCD45±0.2
HFL-4P-FL	32.5 ^{+0.2} ₀	PCD50±0.2	HFL-4S-FL	35 ^{+0.2} ₀	PCD50±0.2

Maximum Tightening Torque

Nm {kgf·cm}

Model	HFL-2P-FL / HFL-2S-FL	HFL-3P-FL / HFL-3S-FL	HFL-4P-FL / HFL-4S-FL
Torque	14 {143}	22 {224}	60 {612}

Interchangeability

Socket and plug of different sizes cannot be connected.

Flow Direction

Fluid flow can be bi-directional when socket and plug are connected.

**Minimum Cross-Sectional Area**(mm²)


Model	HFL-2P-FL HFL-2S-FL	HFL-3P-FL HFL-3S-FL	HFL-4P-FL HFL-4S-FL
Minimum cross-sectional area	32	53	91

Suitability for Vacuum1.3×10⁻¹ Pa {1×10⁻³ mmHg}

Socket only	Plug only	When connected
—	—	Operational

Flow Rate – Pressure Loss Characteristics

[Test conditions] - Fluid : Water - Temperature : 23°C±5°C

**NITTO KOHKI CO., LTD.****Web** www.nitto-kohki.co.jp/e/**Head Office**

2-9-4, Nakaikegami, Ota-ku, Tokyo 146-8555, Japan
 Tel : +81-3-3755-1111 Fax : +81-3-3753-8791
 E-mail : overseas@nitto-kohki.co.jp



DISTRIBUTED BY